

AG05, AG06

**Siemens S7-300®
PROFIBUS® Interface Module
for SIMATIC® Manager V5.5 + SP3
via HMS Anybus® Communicator™**

Software Description



Table of contents

1	General Notes.....	3
1.1	Trademarks	3
1.2	Liability	3
1.3	Limitations	3
1.4	Requirements	4
1.5	Versions Overview	4
1.6	List of Abbreviations	4
2	Hardware Configuration	5
2.1	Setup of Anybus® Communicator™	5
2.1.1	ABC Configuration File	5
2.1.2	Transfer Configuration	5
2.1.3	ABC Cycle Time	6
2.2	Setup of PLC, PROFIBUS® and ABC	7
2.2.1	Add Your PLC to the Project.....	7
2.2.2	Register the GSD Device Description File for ABC	9
2.2.3	Add New Module to Your Hardware Configuration.....	10
2.2.4	Configure the Data Input / Output of ABC	11
3	Software Configuration	13
3.1	Import the SIKO-Library	13
3.1.1	Integrate the Symbole from the Library to Project	13
3.2	Add Required Function Blocks	16
3.3	Call SIKO Function Block Cyclically.....	16
3.3.1	Setup the Input and Output Addresses of the SIKO Function Block	17
3.4	Insert Variable Table for Testing	18
3.5	Complete the Project.....	18
3.6	Work with the Project	19
4	Communication Settings.....	20
4.1	Data Exchange	20
4.2	Parameter Access.....	20
4.2.1	Read Parameters	20
4.2.2	Write Parameters.....	20
4.2.3	Copy Parameters from Read to Write	20
4.3	S-Commands	20
4.4	Counter Value	21
4.4.1	Error Codes.....	23
5	Additional Information	24
5.1	Corresponding Node Address	24
5.2	Priority of “bcStartRead”, “bcStartWrite”, “bcStartCopy” or “bcResetCounterActivity”	24
5.3	Difference in SN5 Protocol Between PLC <-> ABC and ABC <-> SN5 device.....	24

1 General Notes

1.1 Trademarks

All trademarks or brand names including those protected for third parties shall unconditionally be subject to the provisions of the applicable laws governing trademarks and the proprietary rights of the registered owners. All trademarks, brand names or firm names are or may be trademarks or registered trademarks of their respective proprietors and are used only for description and unique identification. All rights not explicitly granted here are reserved.

Failure to explicitly identify trademarks used in this manual does not indicate that a name is free from rights of third parties.

Windows®, Windows® XP are trademarks of Microsoft® Corporation in the USA and other countries.

Anybus® is a registered trademark of HMS Industrial Networks AB, Sweden, USA, Germany and other countries.

SIMATIC® TIA Portal® and S7-300®, S7-400®, S7-1200®, S7-1500® are registered trademarks of Siemens AG.

PROFIBUS® and PROFINET® are registered trademarks of PROFIBUS and PROFINET International (PI).

1.2 Liability

SIKO GmbH assumes no warranty whatsoever regarding topicality, correctness, completeness or quality of the information or software products provided. All liability claims against SIKO GmbH referring to material or immaterial damages caused by using or not using the information or software provided or by using erroneous or incomplete information or software are always excluded.

1.3 Limitations

The library and its function were tested with SIMATIC® S7-300 CPU 6ES7 313-6CE01-0AB0. The interface module was engineered in STL using SIMATIC® Manager V5.5 + SP3.

The configuration file and its function were tested on an Anybus® Communicator™ AB7000. The file was setup using Anybus® Configuration Manager - Communicator RS232/422/485 version v.4.4.1.3 (Win 2000/XP/Vista/7).

1.4 Requirements

- Basic knowledge of handling and programming Siemens systems.
- Familiarity with PROFIBUS®.
- Basic knowledge of setup and handling Anybus® Communicator™
- Familiarity with Anybus® Configuration Manager

1.5 Versions Overview

This manual is related to

- AG05 firmware version ≥ 1.02
- Library "SIKO_SN5-PBvABC_LIB_V501"
- Know-how protected function block FB205 "SIKO_DRV_AG05vPB"
- Anybus® configuration file "SIKO_PB_20-SN5_pattern"
- Anybus® Communicator™ file "HMSB1803.gsd"

1.6 List of Abbreviations

FPB	PROFIBUS®	ABC	Anybus® Communicator™
SN5	SIKONETZ-5	ACM	Anybus® Configuration Manager
SW	Status Word	FB	Function Block
CW	Control Word	DB	Data Block


2 Hardware Configuration

2.1 Setup of Anybus® Communicator™

Please note, that the Anybus® configuration file is designed for a flexible SN5 participant numbers of minimum 1 to maximum 20. Later node address has to be modified according to your network requirements. Please consider a FPB address modification when reading further on.


2.1.1 ABC Configuration File

Start ACM and select configuration file “SIKO_PB_20-SN5_pattern” from the folder “Anybus Config”.




2.1.2 Transfer Configuration

Connect ABC with PC via “RS232 configuration cable” of Anybus accessories.



1. Press "Connect" to go online with the ABC.
2. Press "download to the ABC".

You should have the following view:



2.1.3 ABC Cycle Time

Each transaction consists of "Query" and "Response". The minimum time for a used transaction is about ≥ 10 ms. Each Subnetwork cycle has an overhead of about ≥ 100 ms.

Since the plc cycle time is asynchronous with ABC cycle time the FB integrates a trigger instead of checksum to the SN5 structure. When a master telegram is completed by the FB the trigger will be incremented. The corresponding transaction will be updated by change of state on trigger and exchanges the trigger with checksum byte before the SN5 telegram is send into subnetwork.

The subnetwork reply is checked and checksum byte is exchanged with incremented trigger byte before the telegram is send to plc by ABC. The FB will wait until a valid slave telegram is responded before sending a new telegram. Due to it the minimum time between update cycle amounts to ≥ 110 ms minimum. Please consider this for time critical applications!


2.2 Setup of PLC, PROFIBUS® and ABC

Create New SIMATIC® Manager Project

1. Start the SIMATIC® Manager and create a new project: "File" > "New".
2. Enter the project name "SIKO_example_S7300".
3. Choose a project path.
4. Execute the command "OK".


2.2.1 Add Your PLC to the Project

1. Insert a new S7-300 station by using the command "Insert" > "Station" > "SIMATIC 300 Station"




The new station appears below the project name.

2. Open the hardware configuration tool with command "Edit" > "Open Object"




Now an empty hardware configuration window is opened.

- Choose "Rail" from the folder "RACK-300" of the hardware catalog on the right side. Use drag and drop to move the "Rail" to the hardware configuration.



- Choose the CPU from the hardware catalog and plug it into slot 2 of the rail.




The Properties – PROFIBUS interface DP will open.


NOTICE

The Profibus Address in this example can cause problems under certain circumstances.

5. Create a new Subnet "New..."




6. Confirm the settings with "OK".



7. Close the "Properties – PROFIBUS interface DP" window.

2.2.2 Register the GSD Device Description File for ABC


1. Install GSD for ABC via command "Options" > "Install GSD File..."
2. Browse to the storage location of the GSD file and choose the actual version.
3. Install the selected file.



After installation the ABC is available in the hardware catalog.

2.2.3 Add New Module to Your Hardware Configuration


1. Choose "Anybus Communicator Slave" within the folder "Gateway" from the hardware catalog and attach it to the PROFIBUS subnet using drag and drop.



The Properties – PROFIBUS interface Anybus Communicator SI will open.

NOTICE


The Profibus Address in this example can cause problems under certain circumstances.




2. Enter a valid PROFIBUS® Address, "77" for example.
3. Confirm the settings with "OK".

2.2.4 Configure the Data Input / Output of ABC

1. Add "IN/OUT 4 Bytes (2 word)" from device "Anybus Communicator Slave" of the hardware catalog to the "Devices overview".
2. Add "Universal module" from device "Anybus Communicator Slave" of the hardware catalog to the "Devices overview".



3. Double click on "Universal module" to open "Properties DP slave".



Setup the "I/O type" to "Out – input".


Choose the next "Address" after "IN/OUT 4 Bytes (2 word)".

Modify the "Length" to "10" of "Unit" "Byte".

Select for "Consistent over" "Total length".

4. Confirm the settings with "OK".

5. For each SN5 device a "Universal module" is required.
Select the before modified "Universal Module". Copy "Ctrl + C" and Paste "Ctrl + V" it to the required amount.



6. Save and compile the hardware configuration.

7. Close "HW Config".

The hardware configuration of the project is now complete.

3 Software Configuration

3.1 Import the SIKO-Library


1. Execute command "File" > "Retrieve".
2. Browse to the storage location of the SIKO-library.
3. Select the archive SIKO_SN5-PBvABC_LIB_V501.zip.
4. Execute the command "Open".




5. Select a destination directory accordingly and open it.

3.1.1 Integrate the Symbole from the Library to Project


1. Navigate to the tab "S7 Program(1)" in the project tree
2. Double-click on the object "Symbole" in the right window



3. In the Symbole Editor execute command "Symbole" > "open".
4. Select the library SIKO_SN5-PBvABC_LIB_V501 and "SIKO_FB".
5. Choose "Symbole" and confirm your selection with "OK".



6. Execute command "Window" > "Arrange" > "Vertically".




7. Select ALL by the keystroke combination [Ctrl] + [A].
8. Copying it into the clipboard with the keystroke combination [Ctrl] + [C].
9. Click into line 2 (empty one) of your project symbol table and enter with the keystroke combination [Ctrl] + [V].
10. Delete the the red marked line.

11. Close symbole table "SIKO_FB".
12. Save and close your project symbole table.


3.2 Add Required Function Blocks

Add OB82, OB86 and OB122 to the folder "Blocks".

1. Select folder "Blocks".
2. Execute command "Insert" > "S7 Block" > "1 Organization Block".




3. Enter organization block name "OB82".



4. Repeat steps 2 and 3 with block name "OB86" and "OB122".

3.3 Call SIKO Function Block Cyclically


1. Double click on "OB1".
2. Add function block FB205 from library to main program.



3. Enter the name "DB205" for instance data block.
4. Confirm the message window / selection with "Yes", so the instance DB205 is generated.

3.3.1 Setup the Input and Output Addresses of the SIKO Function Block

To setup the input and output addresses of the function block the decimal address values from the hardware configuration have to be converted to hexadecimal values.



In this example the conversion table looks like this:

Slot 2 – Q address	260...269dec	DC_StartByteOut	W#16#104
Slot 2 – I address	260...269dec	DC_StartByteIn	W#16#104


The input "nNodeId" of the function block must be connected with the set note address of the SN5 device.

In this example the address B#16#5 (5dec) is used.

After set up of the addresses save the settings and close the editor window and confirm "OK".

3.4 Insert Variable Table for Testing

1. While your project is still open execute command "File" > "open"
2. Select the library SIKO_SN5-PBvABC_LIB_V501
3. Execute command "Window" > "Arrange" > "Vertically".
4. Choose "VAT_SIKO_AG05" and copy it into your project using drag and drop.



5. Close library "SIKO_SN5-PBvABC_LIB_V501".

3.5 Complete the Project

1. Select folder "Blocks".
2. Click into the right window and select ALL by the keystroke combination [Ctrl] + [A].
3. Execute the command "Download".




4. Confirm the following message boxes with "Yes" or "OK" respectively.

3.6 Work with the Project

1. Double-click on "VAT_SIKO_AG05".
2. Enable the "Monitor" option in the VAT window.
3. Now you can control the SIKO-AG05 by setting the control bits.

Var - [VAT_SIKO_AG05 -- @SIKO_example_S7300\SIMATIC 300(1)\CPU 313C-2 DP\S7 Program(5) ONLINE]

Table Edit Insert PLC Variable View Options Window Help



	Address	Symbol	Status value	Modify value
1	DB205.DBW 0	"SIKO_DRV_AG05vPB-DATA".DC_StartByteOut	260	
2	DB205.DBW 2	"SIKO_DRV_AG05vPB-DATA".DC_StartByteIn	260	
3				
4	DB205.DBB 8	"SIKO_DRV_AG05vPB-DATA".vnNodeId	5	
5	DB205.DBD 4	"SIKO_DRV_AG05vPB-DATA".vnSetValue	L#0	
6	DB205.DBD 14	"SIKO_DRV_AG05vPB-DATA".vnActualValue	L#2199	
7	DB205.DBB 28	"SIKO_DRV_AG05vPB-DATA".p00_NodeAddress_r	B#16#01	
8	DB205.DBB 29	"SIKO_DRV_AG05vPB-DATA".p00_NodeAddress_w	B#16#01	
9				
10	DB205.DBB 11	"SIKO_DRV_AG05vPB-DATA".vnParameterAdrRead1	B#16#FF	
11	DB205.DBB 12	"SIKO_DRV_AG05vPB-DATA".vnParameterAdrRead2	B#16#FF	
12	DB205.DBB 13	"SIKO_DRV_AG05vPB-DATA".vnParameterAdrRead3	B#16#FF	
13	DB205.DBX 10.2	"SIKO_DRV_AG05vPB-DATA".bcStartRead	false	
14	DB205.DBX 10.3	"SIKO_DRV_AG05vPB-DATA".bcStartWrite	false	
15	DB205.DBX 10.4	"SIKO_DRV_AG05vPB-DATA".bcStartCopy	false	
16	DB205.DBX 10.5	"SIKO_DRV_AG05vPB-DATA".bcResetCounterActivity	false	
17	DB205.DBW 240	"SIKO_DRV_AG05vPB-DATA".vnCounterRead	0	
18	DB205.DBW 242	"SIKO_DRV_AG05vPB-DATA".vnCounterWrite	0	
19	DB205.DBW 244	"SIKO_DRV_AG05vPB-DATA".vnCounterCopy	0	
20	DB205.DBB 21	"SIKO_DRV_AG05vPB-DATA".vnErrorCode1	B#16#00	
21	DB205.DBB 22	"SIKO_DRV_AG05vPB-DATA".vnErrorCode2	B#16#00	
22	DB205.DBX 19.5	"SIKO_DRV_AG05vPB-DATA".bsDone	true	
23	DB205.DBX 19.6	"SIKO_DRV_AG05vPB-DATA".bsBusy	false	
24	DB205.DBX 19.7	"SIKO_DRV_AG05vPB-DATA".bsFaultDataReceive	false	
25	DB205.DBX 20.0	"SIKO_DRV_AG05vPB-DATA".bsComTimeout	false	
26	DB205.DBX 20.1	"SIKO_DRV_AG05vPB-DATA".bsGeneralError	false	
27	// Control Bits =====			
28	DB205.DBX 9.0	"SIKO_DRV_AG05vPB-DATA".bc00_OFF1Enable	true	
29	DB205.DBX 9.1	"SIKO_DRV_AG05vPB-DATA".bc01_OFF2MaxDeceleration	true	
30	DB205.DBX 9.2	"SIKO_DRV_AG05vPB-DATA".bc02_OFF3ProgDeceleratio	true	
31	DB205.DBX 9.3	"SIKO_DRV_AG05vPB-DATA".bc03_IntermediateStop	false	
32	DB205.DBX 9.4	"SIKO_DRV_AG05vPB-DATA".bc04_StartTravelJob	false	
33	DB205.DBX 9.5	"SIKO_DRV_AG05vPB-DATA".bc05_ErrorAcknowledgment	false	
34	DB205.DBX 9.6	"SIKO_DRV_AG05vPB-DATA".bc06_InchingMode1	false	
35	DB205.DBX 9.7	"SIKO_DRV_AG05vPB-DATA".bc07_Inching2Pos	true	
36	DB205.DBX 10.0	"SIKO_DRV_AG05vPB-DATA".bc08_Inching2Neg	false	
37	DB205.DBX 10.1	"SIKO_DRV_AG05vPB-DATA".bc09_KeyEnable	false	
38	// Status Bits =====			
39	DB205.DBX 18.0	"SIKO_DRV_AG05vPB-DATA".bs00_Supply	true	
40	DB205.DBX 18.1	"SIKO_DRV_AG05vPB-DATA".bs01_ReadinessToTravel	false	
41	DB205.DBX 18.2	"SIKO_DRV_AG05vPB-DATA".bs02_InnerLimit		

SIKO_example_S7300\SIMATIC 300(1)\...S7 Program(5)

Abs < 5.2

4 Communication Settings

4.1 Data Exchange

The FB is designed to send or receive in alternation the "nSetValue" (Write, Parameter: 0xFF "Set Point ") or the "nActualValue" (Read, Parameter: 0xFE "Actual Position") respectively, while no specific parameter access is active.

With the "nParameterAdrRead1", "nParameterAdrRead2" and "nParameterAdrRead3" further parameter can be included in the data read cycle. With default value 0xFE the inclusion is disabled.

NOTE: If "bsFaultDataReceive" is indicated the complete data exchange is stopped, while Control and Status Word are still updated! A missing or not responding subnetwork participant is indicated by "bsComTimeout" (0,5sec. + time set in parameter 0x02 Bus Timeout).

4.2 Parameter Access

The present module contains the parameter data in addition to the process data (CW/SW). Parameters that can be changed (read/write) exist in programming as actual value (_r) and as target value (_w) as well. Furthermore, it is differentiated between pure read parameters (only indicated as actual value) and pure write parameters (only indicated as target value).

A rising edge must be applied either to the "bcStartRead" or to the "bcStartWrite" input on the module described here in order to enable a read or write process of one of the variables.

4.2.1 Read Parameters

If a rising edge is applied to the "bcStartRead" input, then all parameters will be read and can be used for further programming. If counter read value is not reset to "0" the read cycle was interrupted by read failure. This indicates to a communication failure.

4.2.2 Write Parameters

If a rising edge is applied to the "bcStartWrite" input of the module, then all parameters will be transferred to the module. If counter write value is not reset to "0" the write cycle was interrupted by a write failure. This indicates to a communication failure or parameter value is beyond range of value accepted by AG05.

4.2.3 Copy Parameters from Read to Write

If a rising edge is applied to the "bcStartCopy" input of the module, then all actual values (_r) are copied to their corresponding target values (_w).

4.3 S-Commands

After executing a S-Command a read cycle is been triggered to refresh all actual values (_r).

4.4 Counter Value

Count read value	Count write value	Name	Value range (dec)	Default
	1	0xA8 Programming Mode On/Off	0 ... 1	0
1	2	0x00 Note address	0 ... 31	1
2	3	0x01 Baud rate	0 ... 2	1
3	4	0x02 Bus Timeout	0 ... 20	20
4	5	0x03 Response parameter to a setpoint write access	0 ... 8	1
5	6	0x04 Keys enable time	1 ... 60	3
6	7	0x05 Key function enable	0 ... 1	0
7	8	0x07 LED 2 orange	0 ... 1	1
8	9	0x08 LED 1 red	0 ... 1	1
9	10	0x09 LED 1 green	0 ... 1	1
10	11	0x0A Decimal places	0 ... 4	0
11	12	0x0B Display divisor	0 ... 3	0
12	13	0x0C Direction indication function	0 ... 2	0
13	14	0x0D Display orientation	0 ... 1	0
14	15	0x0E Programming mode Configuration	0 ... 1	0
15	16	0x0F PIN change	0 ... 99999	0
16	17	0x10 Controller parameter P	1 ... 500	300
17	18	0x11 Controller parameter I	0 ... 500	2
18	19	0x12 Controller parameter D	0 ... 500	0
19	20	0x13 a - Pos	1 ... 100	50
20	21	0x14 v - Pos	Gear 66:1 => 1 ... 75 98:1 => 1 ... 50	10
21	22	0x15 a - rot	1 ... 100	50
22	23	0x16 a - inch	1 ... 100	50
23	24	0x17 v - inch	Gear 66:1 => 1 ... 75 98:1 => 1 ... 50	10
24	25	0x18 ü - Numerator	1 ... 10000	1
25	26	0x19 ü - Denominator	1 ... 10000	1
26		0x1A Encoder resolution		720
27	27	0x1B Sense of rotation	0 ... 1	0
28	28	0x1C Spindle pitch	0 ... 1000000	0
29	29	0x1E Offset	-999999 ... 999999	0
30	30	0x1F Calibration value	-999999 ... 999999	0
31	31	0x20 Pos- window	0 ... 1000	10
32	32	0x21 Pos type	0 ... 2	0
33	33	0x22 Loop length	0 ... 30000	360

Count read value	Count write value	Name	Value range (dec)	Default
34	34	0x23 Inpos mode	0 ... 2	0
35	35	0x24 Delta Inch	-1000000 ... 1000000	720
36	36	0x25 Acceleration type with Inching mode 2	0 ... 1	0
37	37	0x26 Inching 2 Offset	10 ... 100	100
38	38	0x27 Stop mode inching 2	0 ... 1	0
39	39	0x28 Operating mode	0 ... 1	0
40	40	0x29 Limit 1	-9999999 ... 9999999	99999
41	41	0x2A Limit 2	-9999999 ... 9999999	-19999
42	42	0x2C Current limiting	25 ... 110	110
43	43	0x2D Contouring error limit	1 ... 30000	400
44	44	0x30 Display value of 2nd line	0 ... 7	0
45	45	0x33 Display divisor application	0 ... 1	0
46		0x60 Output stage temperature		0
47		0x61 Voltage of control		0
48		0x62 Voltage of output stage		0
49		0x63 Voltage of battery		0
50		0x64 Motor current		0
51		0x65 Device code		0
52		0x66 Display controller software version		0
53		0x67 Motor controller software version		0
54		0x68 Serial number		0
55		0x69 Production date		0
56		0x6A Gear reduction		0
57		0x6B Actual position		0
58		0x6C Actual rotational speed		0
59		0x80 Number of errors		0
60		0x81 Error 1		0
61		0x82 Error 2		0
62		0x83 Error 3		0
63		0x84 Error 4		0
64		0x85 Error 5		0
65		0x86 Error 6		0
66		0x87 Error 7		0
67		0x88 Error 8		0
68		0x89 Error 9		0
69		0x8A Error 10		0
	46	0xAA FreezeAV	0 ... 1	0
70		0xFA System status word		0

Count read value	Count write value	Name	Value range (dec)	Default
71		0xFE Actual value		0
72		0xFF Set point		0
	47	0xA0 System Command	1 ... 9	0

4.4.1 Error Codes

If a communication error occurs, there is an error code present at the outputs "nErrorCode1" and "nErrorCode2". Please refer to the AG05 manual (keyword: error codes) for a complete description of these error codes.

5 Additional Information

5.1 Corresponding Node Address

Since the different SN5 devices can be commanded to change the actual used node address, make sure, that before a "bcStartWrite" is executed, "vnNodeId" (temporary address) and "p00_NodeAddress_w" (set address) are adjusted accordingly. Otherwise a lost of communication after cold start or software reset is possible!

5.2 Priority of "bcStartRead", "bcStartWrite", "bcStartCopy" or "bcResetCounterActivity"

If one of "bcStartRead", "bcStartWrite", "bcStartCopy" is high/true the others are blocked, except "bcResetCounterActivity". The priority is: "bcStartRead", "bcStartWrite", "bcStartCopy".

There is no timing or device condition to execute either "bcStartRead" or "bcStartCopy". For execute "bcStartWrite" the device must be without movement and "vnCounterRead" and "vnCounterCopy" are inactive.

Otherwise "bcStartWrite" is not executed or delayed!

If "bcResetCounterActivity" is high/true ALL counters are set to "0" as well as the internal status of "bcStartRead", "bcStartWrite", "bcStartCopy".


5.3 Difference in SN5 Protocol Between PLC <-> ABC and ABC <-> SN5 device

The FB is creating a protocol string according to the device manual but with one network required modification, which is a trigger byte instead of checksum byte at the protocol end.

This is required since the plc cycle and update time is much higher than from the ABC. Every time the FB has completed the string, it increases the trigger value by one. The ABC configuration is designed to check this plc trigger. Every time the ABC application update cycle comes together with the plc trigger change, the ABC configuration exchanges the trigger byte with a checksum byte and sends the SN5 protocol into the subnet.

The addressed SN5 slave replies with a respectively protocol and the ABC performs the checksum test. If positively checked, the ABC exchanges the checksum byte with a trigger byte and transfers the protocol string to the master plc. This trigger is monitored (fix 500 ms) and used together with "p02_BusTimeout_r" to create "bsComTimeout".

The protocol string with trigger byte recived from and transmitted to plc can be viewed in the ABC "Node Monitor". Go online with ABC while application runs. Click the node underneath "Subnet". Then start the "Node Monitor" which should be selectable now:



You should have similar few:

In Area 204 bytes (512)										Out Area 204 bytes (512)										General Area 0 bytes									
0000	0	0	22	22	0	5	FE	1		0200	0	0			0	5	FE	0		0400									
0008	3	0	0	1	F4	11	1	6		0208	7	0	0	0	0	69	1	6		0408									
0010	FE	1	3	0	0	2	58	11		0210	FF	0	7	0	0	0	A	64		0410									
0018	0	0	0	0	0	0	0	0		0218	0	0	0	0	0	0	0	0		0418									
0020	0	0	0	0	0	0	0	0		0220	0	0	0	0	0	0	0	0		0420									
0028	0	0	0	0	0	0	0	0		0228	0	0	0	0	0	0	0	0		0428									
0030	0	0	0	0	0	0	0	0		0230	0	0	0	0	0	0	0	0		0430									
0038	0	0	0	0	0	0	0	0		0238	0	0	0	0	0	0	0	0		0438									

In the "Out Area ..." you can see what is send from plc. In this example the ID5 is requested for current position.

In the "In Area ..." you can see what comes from subnet. In this example the ID5 replies current position (1F4 (h) = 500 (d)).

To the ID 6 the target position (258 (h) = 600 (d)) is send and confirmed.

Please keep in mind, that the 10th Byte is not checksum but trigger value!